Wirings

Cable Connections EasyVision RAD Standalone Ultra 5	Z2-1
Cable Connections EasyVision RAD Client Ultra 5	Z2-2
Cable Connections EasyVision RAD Server/Standalone Ultra 10	Z2-3
Cable Connections EasyVision RAD Client Ultra 10	Z2-4
Cable Connections EasyVision RAD Server/Standalone Ultra 60	Z2-5
Cable Connections EasyVision RAD Client Ultra 60	Z2-6
Video Connections EasyVision RAD Ultra 5	Z2-7
Video Connections EasyVision RAD Ultra 10	Z2-8
Video Connections EasyVision RAD Ultra 60	Z2-9
Network/Modem Connections Client/Server Ultra 10	Z2-10
Network/Modem Connections Client/Server Ultra 60	<i>7</i> 2-11